



# **Low Gravity Cryogenic Liquid Acquisition for Space Exploration**

**David J. Chato<sup>1</sup>, Jason W. Hartwig<sup>1</sup>, Enrique Rame<sup>2</sup>,  
John B. McQuillen<sup>1</sup>**

**<sup>1</sup>NASA Glenn Research Center, Cleveland, OH, USA**

**<sup>2</sup>National Center for Space Exploration Research, Cleveland, OH, USA**

**29th American Society for Gravitational and Space  
Research and 5th International Symposium for Physical  
Sciences in Space  
Session: Fluid Physics 7  
November 6, 2013**

# Cryogenic Propellant Technology Development



*To enable cryogenic propellant depots, the Cryogenic Propellant Storage and Transfer (CPST) project has developed a plan to raise the Technology Readiness Level (TRL) of numerous Cryogenic Fluid Management (CFM) technologies:*

## **FY11-13 Technology Maturation Ground Testing (TRL 5)**

- Liquid Hydrogen (LH<sub>2</sub>) Radio Frequency Mass Gauge (RFMG)
- Multi-Layer Insulation (MLI) Penetration Degradation
- Liquid Nitrogen (LN<sub>2</sub>) & LH<sub>2</sub> Liquid Acquisition Device (LAD)/Transfer Line Chill
- Active Thermal Control (Reduced Boil-Off LH<sub>2</sub> & Zero Boil-Off Liquid Oxygen (LOX))
- MLI Vibe Test




## **Technology Demonstration Mission**

- Demonstrate in-space storage and transfer of cryogenic propellants (TRL 6)



## **Cryogenic Depots for future manned and robotic missions (TRL 9)**



# LAD Overview – Fundamental Fluid Physics



Subsystem requirement - transfer vapor free propellant from a tank to the transfer line en route to an engine or receiver tank (depot)


Separation of liquid and vapor phases governed by lowest achievable potential energy state

## Fluid transfer in 0-g

- Surface tension force is the driver
- Liquid → outer walls , vapor → center

### Single phase flow strategy:

- Full “communication” device – usually a **fine mesh** or vane alongside tank wall
- Micron sized pores in screen separate phases and wick liquid into channel







# Screen Channel Liquid Acquisition Devices



- Screen channel liquid acquisition devices (LADs) or gallery arms are best in multi-directional, multi-g environments, high flow rates
- Warp/shute wires characterize the mesh (ex. 325x2300 )
- LADs rely on capillary flow, wicking, and surface tension forces to maintain liquid flow



- Screen channel LADs fail when vapor is ingested across the screen during liquid outflow:  $\Delta P_{total} > \Delta P_{BP}$
- Differential pressure across a screen pore that overcomes the surface tension of the liquid at that pore:

$$\Delta P_{BP} = \frac{4\gamma_{LV} \cos \theta_C}{D_P}$$


- Small pore diameters ( $< 20 \mu\text{m}$ ) are favorable for  $\text{LH}_2$  systems to counter low surface tension (2 mN/m)
- $\text{LH}_2$  Normal Boiling Point (NBP) bubble point of a 325x2300 screen is only 575 Pa (0.08 psi)

# Low-g Liquid Acquisition




## *Prior Accomplishments:*


- Measurement of bubble point (breakthrough) pressure for saturated LCH<sub>4</sub> completed CCL-7 2007.
- Measurement of bubble point (breakthrough) pressure for saturated LOX completed CCL-7 2008.
- Measurement of bubble point at elevated temperature and pressure conditions for LO<sub>2</sub> and LCH<sub>4</sub>. 2010
- Conducted outflow tests at representative flow conditions for main engine burns to assess pressure drop across the screen channel LAD and to determine the breakthrough pressure at those conditions 2010



Screened Sump Conceptual Design for Lunar Lander Ascent Stage





High Flow rate LAD Channel Design



Test fixture (CCL-7) for bubble point pressure

# Static LAD Bubble Point screen/cup






# Effect of Screen Mesh on Static Bubble Point



- $\text{LH}_2$  near normal boiling point
- GHe temperature near screen close liquid temperature for all points
- 450x2750 buys >25% margin over the 325x2300 screen (based on comparison of test data curve fits)
- 510x3600 prediction curve and data both lie below 450 data




Screen	Room Temperature		# warp	# shute	d warp [ $\mu\text{m}$ ]	d shute [ $\mu\text{m}$ ]	Absolute $\mu$ rating
	Pore Diameter [ $\mu\text{m}$ ]						
325x2300	14.8		325	2300	38.1	25.4	8 to 9
450x2750	11.8		450	2750	26	20	6 to 7
510x3600	15.9		510	3600	26	15.2	5 to 6

*There may be an optimal warp to shute diameter ratio which maximizes bubble point pressure*

# Effect of Temperature, Pressurant Gas Type



$$\Delta P_{BP} = \frac{4\gamma_{LV} \cos \theta_C}{D_P}$$



- *Rigorous parametric investigation of influential parameters on LH2 LAD performance (Hartwig et al. 2013)*

1. *Mesh*
2. *Liquid*
3. *Liquid Temperature*
4. *Liquid Pressure*
5. *Pressurant Gas Type*
6. *Pressurant Gas Temperature*

- $\Delta P_{BP}$  sets upper limit on performance
- 450  $\Delta P_{BP}$  scales inversely with liquid temp. Subcool w/ GHe yields an average 39% difference over GH2 pressurization
- 4/6 parameters summarized here
- For all points here,  $T_{GAS} = T_{LIQUID}$



# Recent Full Scale LH2 LAD Outflow Tests



## Objective:

- Quantify the LAD stability (no LAD breakdown) due to transfer line chill down transient dynamic pressure perturbations during outflow
- Quantify LAD breakdown as a function of liquid temperature, LAD outflow rate

## Significance:


- Completed over 100 flow through screen tests, as well as gaseous helium calibration, further analysis is required to eliminate anomalous tests from the results.
- Completed over 20 Inverted Outflow LAD breakdown tests; Thermodynamic Vent System (TVS) cooled LAD shows superior performance



Test Tank



Flight Representative LAD Installed



Top Down View

# Flow-through-Screen Research Hardware



## Hardware Configuration

- Flow-through-screen hardware mounted on test tank lid
- 2 screens mounted in series (450x2750, 325x2300)
- Flow routed vertically upward
- Screens spaced out to overcome entrance effects @ highest flow rates @ second screen
- Multiple DPTs for each screen to cover flow range
- 2 Venturi flow meters (FMs) used to measure flow
- Both screens passed pretest Isopropyl Alcohol (IPA) bubble point test




325x2300



450x2750



2" OD x 0.875" ID



# Temperature Dependence of $\Delta P_{FTS}$




- All data is for exact same 325x2300 screen sample
- Our Ghe and LH2 data bound the single Armour and Cannon (A&C) curve fit to historical data
  - Important to note that A&C prediction based on multiple screen styles (square, Dutch Twill) and gases
- Evidence that  $\Delta P_{FTS}$  may be temperature dependent (higher flow losses at LH2 temps due to possible screen shrinkage)



# 325x2300 TVS Cooled LAD




- From previous LOX, LCH<sub>4</sub>, LH<sub>2</sub> bubble point tests, cooling the liquid at the screen lowers  $T$ , increases  $\gamma$ , increases  $\Delta P_{BP}$
- Gain in  $\Delta P_{BP}$  should translate into lower breakdown heights
- Triangular backed
  - Room for heat exchanger
  - Match hydraulic diameters
- Perforated plate backed screens
  - Enhanced wicking
  - Added structural support against launch loads
  - Cost: reduces to 63% screen open area




# 325x2300 TVS Cooled LAD Principle of Operation



- Small amount of fluid is drawn from the tank, expanded across a JT orifice (constant enthalpy), thus cooled and circulated through the flight-like LAD as counterflow HEX to cool the fluid inside the LAD
- HEX designed to flash inside cooling coil inside LAD
- Measure DPT across JT, dT across TVS
- LAD originally designed to cool LH2 inside channel 6°R @ 50 psia saturated liquid at a JT flow rate of  $\sim 0.0025$  lbm/s ( $< 6.67\%$  of lowest LAD outflow rate)



# 325x2300 Standard Channel




- Performance measured in terms of exposed screen length from top of channel
- Could also consider exposed screen length
- LAD breaks down when
$$\Delta P_{total} > \Delta P_{BP}$$
- **“Breakdown” = ingestion of a single GHe bubble**

## Trends

- Breakdown height scales linearly with liquid temperature (earlier breakdown in warmer liquid)
- Breakdown height scales with flow rate (earlier breakdown @ higher flows)
- Data correlates well with model




# 325x2300 Flight Channel



## Trends

- Breakdown height scales with liquid temperature (earlier breakdown in warmer liquid)
  - Breakdown height scales inversely with flow rate (later breakdown @ higher flows)
  - Data doesn't correlate well with model
- 
- TVS cooling flattens temperature dependence
  - Perforated plate enhances wicking

# 325x2300 LAD TVS Performance



- All six tests in 15 psia saturated liquid
- 3 tests with TVS engaged/3 tests off


## Trends

- TVS improves performance of 325x2300 Flight LAD by an average 4.9% of total LAD length in 15 psia sat. liquid

# Cryogenic Bubble Point Pressure Model



- Model determines static bubble point pressure for any screen, liquid, operating temperature and pressure, and pressurant gas type and temperature
- Model anchored to data (semi-analytical, semi-empirical)
- Accounts for:
  - Updated surface tension model
  - Temperature dependent pore diameter
  - Differences between pressurization schemes
  - Effect of subcooling the liquid
  - Effect of raising the pressurant gas temperature (relative to liquid)




$$\Delta P_{BP}(\text{screen}, T, P, T_{gas}) = \frac{4\gamma \cos \theta}{D_p(T)} n_1(\text{gas}, T) \left( 1 + n_2(\text{gas}) \frac{P - P_{SAT}(T)}{P_{REF}} \right) \left( 1 - n_3(\text{gas}) \frac{T_{GAS} - T}{T_{REF}} \right)$$

- $n_1, n_2, n_3$ , constants



# Inverted Outflow Data vs. Model



- 325 TVS cooled outperforms 325, despite post-test degraded performance in IPA
- Disparity between data and model due to:

1. % area in FTS term

$$\Delta P_{FTS} \propto \frac{1}{A_C}$$

less flow area = more  $\Delta P_{FTS}$   
→ shift the data up

2. Degradation in performance from pre to post IPA tests



# Findings and Recommendations

# Summary of Results – LADs



1. Bubble point scales with the mesh of the screen for 325x2300 and 450x2750 screens.
  - 450 buys us 27% margin over 325 => higher flow rates during transfer
  - Pore diameter is both screen and temperature dependent
2. Bubble point scales with the surface tension of the liquid
3. GHe pressurization = gain factor; GH2 pressurization = degradation factor
4.  $\Delta P_{\text{FTS}}$  is temperature dependent, as is the bubble point pressure
  - $\Delta P_{\text{FTS},450} < \Delta P_{\text{FTS},325}$  ·  $\Delta P_{\text{BP},450} > \Delta P_{\text{BP},325}$ . Hints at existence of optimized mesh for low surface tension liquid acquisition. (desire for flight is highest for  $\Delta P_{\text{BP}}$  for lowest  $\Delta P_{\text{FTS}}$ ).
5. Frictional and Dynamic pressure losses also higher than anticipated @ LH2 temps.
6. Inverted vertical outflow breakdown point dominated by liquid temp; second order dependence on liquid outflow rate
  - TVS cooling always improves performance (cooling supports higher outflow rates)
  - Subcooling + pressurizing w/ GHe always improves performance (9% in 15 psia saturated liquid )



# Acknowledgements



<b>Research</b>	Dave Chato	<b>Facility</b>	Lori Arnett	<b>Transportation</b>	Lester Brooks
	Jason Hartwig		Helmut Bamberger	<b>&amp; Handling</b>	Travis Faulkner
	John Mcquillen		Moses Brown		Carl Fuchs
	Enrique Rame		Tim Czaruk		Greg Kearney
	Samuel Darr		Chris DeTardo		Rick Michalson
	Alex Scammel		Drew Fausnaugh		Bob Silloway
			Arnie Kuchenmeister		Brooks Smith
<b>Design</b>	Bob Buehrle		Diane Legallee		Pat Spohn
	Randy Clapper		Jay Owens		Doug Tyson
	Larry Cola		Joe Puskas		Todd Zwilling
	Dan Hauser		Olen Reed	<b>Management</b>	Ed Becks
	Maureen Kudlac		Anthony Roberts		Mike Doherty
	Frank Quinn		Craig Robinson		Ken Fisher
	Jerry Vera		Alex Sgondea		Joe Gaby
			Mark Springowski		Mark Hyatt
<b>DAQ</b>	Marivell Baez		Bob Tomsic		Kamana Katiyar
	Jerri Vokac		Bill Vaccariello		Mark Klem
	Jason Edwards		Tiffany Vanderwyst		Mike Meyer
					Sue Motil
<b>Technical</b>	Ben Stiegemeier				Brian Rice
	Chris Popp				Bruce Rosenthal
	Geoff Statham				John Schubert